1 bit DRAM Tester Rev 6

©2021-2023, Simon Raybould

(sie@sieraybould.net)

Last Updated 3rd October 2023

This DRAM tester supports most 1 bit DRAM devices from 4Kbit (e.g. MCM4096 or M4027P) to 1024K bit (e.g. TMS41256).


It can also test and identify parts that were sold with known faulty blocks, such as 4108 (partially failed 16Kb parts) and TMS4532/OKI 3732 (partially failed 64Kb parts) used in home computers in the 1980s. The LEDs will show which of the blocks are working and therefore if the part could be used as a 32Kbit DRAM.

The tester also supports the 128Kbit parts that were two 64Kb chips piggybacked together. Those parts have two RAS pins (RAS1and RAS2) which the tester identifies during the test.

It has a simple power requirement, needing just 5V and drawing less than 100mA, so it can be powered from any USB port with a standard micro-USB cable.

Please note that DRAM memories are VERY sensitive to static electricity. Please make sure that you adhere to ESD precautions when handling DRAM parts.

Please also note that the left hand socket is for ONLY for memories that have 4 power pins as shown in the photo below (+12V, +5V, -5V and GND).



Please double check, before pressing the start button, that any part you have put in the left hand socket has power pins as shown above. Failure to do so may result in damage to the chip and/or the tester.

How to Use


- 1. Connect the board to a USB port to provide power.
- 2. Put the DRAM chip in the correct socket: The left socket is for parts that require -5V on pin 1, +12V on pin8, +5V on pin 9 and 0V on pin 16 (e.g. MCM4096, M4027P, 4108 and 4116), all other types should ONLY be tested in the middle or right socket.
- 3. Press the start button and wait for the result to show on the LEDs.

 Please note that the LEDs will flicker while the DRAM is being tested, this is normal.

The Output LEDs

There are 4 RGB LEDs on the board arranged as a 2x2 array to show the test result.

On initial power-up, the LEDs should be as shown below:



This indicates that the board is working correctly.

When you press the button, all four LEDs will light YELLOW and when you release it the testing will start. While the test is running, the LEDs will flicker white and when the test is complete, the result will be shown.

If the part tries to draw too much current (e.g. due to an internal fault) then the auto-reset fuse may trigger causing the board to reset and show the four colour pattern above. In that case the DRAM is faulty.

First the tester detects the number of rows and columns in the DRAM and splits both into two halves (unless smaller than 16Kbit). The lower half of the rows are shown on the upper LEDs and the upper half are shown on the lower LEDs. The lower half of the columns are shown on the left LEDs and the upper half are shown on the right LEDs.

| DRAM Capacity | No. of Rows/Cols | Capacity per LED | Pass Colour |
|---------------|------------------|------------------|-------------|
| 4Kbit | 64 | 4Kbit | Blue |
| 16Kbit | 128 | 4Kbit | Blue |
| 64Kbit | 256 | 16Kbit | Green |
| 256Kbit | 512 | 64Kbit | Magenta |
| 1024Kbit | 1024 | 256Kbit | Cyan |

Good 4Kbit blocks are shown as BLUE. Good 16Kbit blocks are shown as GREEN. Good 64Kbit blocks are shown as MAGENTA. Good 256Kbit blocks are shown as CYAN. Bad blocks are shows as RED. Blocks not detected do not illuminate that LED.

Blocks that pass at high speed but then fail the retention time tests will flash. This indicates that the part might work but the DRAM is out of spec.

Tested Devices

The tester will support many more parts than listed here. Basically any part with the same power requirements, pinout and refresh rate as the ones listed below should also work in that same socket. The list below are just examples to guide you on which test socket to use.

Please make sure you do not put any part in the left hand socket that does not have the +5V. +12V, -5V power requirements with the same pinout as a 4116 or the part and/or tester may be damaged.

LEFT Socket (16 pins)

- Mostek MK4027P
- Motorola MCM4096
- Mostek MK4108-x0
- TI TMS4108-x0
- Mostek MK4108-x1
- TI TMS4108-x1
- ITT/STC 4116
- Mostek MK4116

MIDDLE Socket (16 pins)

- Mostek MK4516
- Hitachi HM4816
- Intel 2118
- TI TMS4532xL3
- TI TMS4532xL4
- OKI M3732L
- OKI M3732H
- 4164
- TI TMS4164
- Samsung KM4128
- TI TMS4256
- 41256

RIGHT Socket (18 pins)


- Motorola MCM511000
- Hitachi HM511000

More Detail

Here is some more detail on how to interpret the output on the LEDs.

Parts with Capacity up to 16Kbit

For parts with a capacity up to 16Kbit (4Kbit, 8Kbit & 16Kbit) such as M4027P, MCM4096, 4108 and 4116, each LED represents a 4Kb block arranged as follows:




A good block will show as BLUE and a bad block as RED. A block that fails the retention time tests will flash BLUE.

Missing blocks do not light the corresponding LED.

Parts with Capacity over 16Kbit up to 64Kbit

Parts with a capacity over 16Kbit up to and including 64Kbit (32Kbit & 64Kbit) such as TMS4532, M3732 and 4164, each LED represents a 16Kb block arranged as follows:




A good block will show as GREEN and a bad block as RED. A block that fails the retention time tests will flash GREEN.

Missing blocks do not light the corresponding LED.

Parts with Capacity over 64Kbit up to 256Kbit

Parts with a capacity over 64Kbit up to and including 256Kbit (128Kbit & 256Kbit), each LED represents a 64Kb block arranged as follows:




A good block will show as MAGENTA and a bad block as RED. A block that fails the retention time tests will flash MAGENTA.

Missing blocks do not light the corresponding LED.

Parts with Capacity over 256Kbit up to 1024Kbit

Parts with a capacity over 256Kbit up to and including 1024Kbit, each LED represents a 256Kb block arranged as follows:



A good block will show as CYAN and a bad block as RED. A block that fails the retention time tests will flash CYAN.

Missing blocks do not light the corresponding LED.

Example Good Results

Empty box means LED should be off.

Box with a cross means "don't care" so could be colour or red but should be lit.

| Part | Size | Socket | Pass |
|------------------|------------------------------|--------|------|
| Mostek MK4027P | 4 Kbit | Left | |
| Motorola MCM4096 | 4 Kbit | Left | |
| Mostek MK4108-x0 | 8 Kbit (4116 even cols only) | Left | |
| TI TMS4108-x0 | 8 Kbit (4116 even cols only) | Left | |
| Mostek MK4108-x1 | 8 Kbit (4116 odd cols only) | Left | |
| TI TMS4108-x1 | 8 Kbit (4116 odd cols only) | Left | |
| ITT/STC 4116 | 16 Kbit | Left | |
| Mostek MK4116 | 16 Kbit | Left | |
| Mostek MK4516 | 16 Kbit | Middle | |
| Hitachi HM4816 | 16 Kbit | Middle | |
| Intel 2118 | 16 Kbit | Middle | |
| TI TMS4532xL3 | 32 Kbit | Middle | |
| TI TMS4532xL4 | 32 Kbit | Middle | |
| OKI M3732L | 32 Kbit | Middle | |
| OKI M3732H | 32 Kbit | Middle | |
| TI TMS4164 | 64 Kbit | Middle | |
| Samsung KM4128 | 128 Kbit (piggyback) | Middle | |
| TI TMS4256 | 256 Kbit | Middle | |
| MCM511000 | 1024 Kbit | Right | |
| HM511000 | 1024 Kbit | Right | |

Approximate Test Times

Here are some examples of the test times for this tester:

| Size | Approximate Test Time |
|--------|--|
| 4Kb | Under 2 seconds |
| 16Kb | About 5 seconds |
| 32Kb | 10-20 seconds depending on number of good blocks |
| 64Kb | About 20 seconds |
| 128Kb | About 42 seconds |
| 256Kb | About 82 seconds |
| 1024Kb | About 330 seconds |

The tests are made first at high speed, then at lower speed such that the refresh period is close to the specified maximum retention time for the part being tested.

That means close to 4ms for 64 rows on an M4027 or MCM4096, 2ms for 128 rows on a 4116 part and close to 4ms for the 256 rows on a 4161 or 41256 part. If the tests pass at high speed but then subsequently fail at the lower speed then the result LED will flash rather than be steady on.

This ensures that any issues that only occur near to the maximum retention time are also detected by this tester.

So you can be sure that if a part tests as good in this tester then it should work well in a real application. Please bear in mind that a part that fails may still work in a real application, it all depends on whether the failing location is used in the application and, even if it is, whether the failed location causes any noticeable symptoms.

The Test Procedure

- 1. Measure the size of the DRAM.
- 2. High speed tests
 - Fill the RAM with 0s and check that
 - Fill the RAM with 1s and check that
 - Even Hash test
 - Odd hash test
 - Fill the RAM with random data and check that
 - Repeat the above random data test several times
- 3. Lower speed tests to test the retention time
 - Fill the RAM with random data and check that
 - Odd hash test
 - Even hash test
 - Repeat the above random data test several times
 - Fill the RAM with 1s and check that
 - Fill the RAM with 0s and check that

NOTE

If you have a Rev6 tester and there is not an electrolytic capacitor fitted across the outer two holes of the 4 holes above the microcontroller, as shown below, then please fit that to solve issues relating to the board locking up occasionally.

